

## PAS V3 Pumping Unit



## Component Technical Manual



Document Ref 903647-001 Rev - 3 08/2008 Great care has been taken in the preparation of this manual however Tokheim shall not be liable for any misunderstanding, errors and/or loss or defect arising from the use of this manual.

Tokheim shall not be liable for damage to the product, nor for personal or third party injury, caused by incorrect use of the product or by attempts to maintain or to repair the product by parties other than those fully trained by Tokheim or by its accredited third party representatives.

Please contact your nearest service department, at the relevant address printed on the back cover of this manual, should any aspect of this manual be unclear.

© Copyright by Tokheim. All intellectual rights arising from, accruing to, and residing in this manual belong to Tokheim. No part of this document may be reproduced in any form without the express written permission of Tokheim.

Tokheim reserves the right to apply changes to this document and the equipment without further notice.

Date	Revision	Page	lssue	Reason
01/03/2002	1	All	A	Original Issue
13/04/2006	2	All	В	Copyright and disclaimer notice added; contents updated; pages renumbered; drawings redrawn; new pages inserted; revised addresses
28/08/2008	3	All 2-2 2-5	C	Copyright and disclaimer notice added; contents updated; pages renumbered; drawings redrawn; new pages inserted; revised addresses New tech info added (min inlet vacuum) Above ground tank applications added

## **REVISION RECORD**

This page is intentionally blank

## CONTENTS

1	GEN	ERAL		
	1.1	Definiti	ons	1-2
	1.2	Configu	arations	1-2
2	OPE	RATING	DESCRIPTION	
	2.1	Technic	cal Characteristics	
	2.2	Alignm	nent of the Pump	2-3
	2.3	Schema	atic Diagram of Operating Principles	2-4
	2.4	Schema	atic Diagram References	2-4
	2.5	Operati	ng Description	
		2.5.1	Pumping, Filtration & By-Pass	
		2.5.2	Above Ground Tank Applications	
		2.5.3	Air Separation	
		2.5.4	Outlet Valve	
		2.5.5	Recovery Chamber	
		2.5.6	Vent to Atmosphere	2-7
		2.5.7	Draining of the PAS	2-7
		2.5.8	V-belt Transmission	2-7
		2.5.9	Motors	
3	FAIL	<b>URE DI</b>	AGNOSIS	
	3.1	Failure	Diagnosis	
	3.2	Flow C	'harts	
		3.2.1	No Fuel Flow	
		3.2.2	Reduced Fuel Flow	
		3.2.3	Uneven Fuel Flow	
		3.2.4	Closing of the Overflow Valve	
		3.2.5	Excessive Noise	
4	TRO	UBLESH	HOOTING	4-2
	4.1	Outlet	Pressure	
	4.2	Inlet Pi	ressure	
	4.3	Air Ver	nt	
	4.4	Interna	l Air Entry in the Pump	
	4.5	Externa	al Problems up-stream the PAS	
	4.6	Excessi	ive Head Loss	4-4
	4.7	Air Ent	ry on the Pipework to the Storage Tank	
5	SPAI	RE PART	IS AND MAINTENANCE TOOLS	5-3
	5.1	Freque	ntly Used Spare Parts	
	5.2	Explod	ed Views and Parts Lists	
		5.2.1	Front View	
		5.2.2	Back View	
		5.2.3	Top View	5-10
	5.3	Mainte	nance Kits	
	5.4	Referen	nces of Specific Tools	
6	PRO	BLEM R	REPORT FORM FOR THE PAS V3 PUMP	

This page is intentionally blank

## CONTENTS

1	GENE	RAL	1-	·2
	1.1	Definitions	. 1-	-2
	1.2	Configurations	. 1-	-2

#### 1 GENERAL

|--|

¤ PAS V3:	Commercial name of the PAS version 3
	There is one hydraulic block for both 80 l/min and 130 l/min flow
¤ PAS V3 80:	Name used when the delivery is 80 l/min (4.8 m <sup>3</sup> /h)
	The PAS is equipped with a 1kW 1400rpm motor
¤ PAS V3 130:	Name used when the delivery is $130  l/min (7.8  m^3/h)$
	The PAS is equipped with a 1.5kW 2800rpm motor
<b>¤</b> Type plate:	

## Gas Separator for liquid fuel. Serial number: OIML R117/1995-NL-01.04 Q<sub>max</sub> 130 L/min Diesel P<sub>max</sub> 3,5 bar P<sub>min</sub> 2,3 bar Q<sub>max</sub> 80 L/min Gasoline/Diesel P<sub>max</sub> 3,5 bar P<sub>min</sub> 1,7 bar

#### **IMPORTANT NOTE**

When reporting a case of anomaly or malfunction, the name PAS V3 has to be mentioned together with the serial number indicated on the type plate near the pump pulley (see picture above). It is also possible to fill in a problem report (see Section 6) to report malfunction or anomalies.

#### 1.2 Configurations

Standard configurations of the PAS V3 80 l/min





Standard configurations of the PAS V3 130 l/min



h

This page is intentionally blank

## CONTENTS

2	OPER	ATING D	DESCRIPTION	2-2
	2.1	Technical	Characteristics	. 2-2
	2.2	Alignmer	nt of the Pump	. 2-3
	2.3	Schemati	c Diagram of Operating Principles	. 2-4
	2.4	Schemati	c Diagram References	. 2-4
	2.5	Operating	Description	. 2-5
		2.5.1	Pumping, Filtration & By-Pass	. 2-5
		2.5.2	Above Ground Tank Applications	. 2-5
		2.5.3	Air Separation	. 2-5
		2.5.4	Outlet Valve	. 2-6
		2.5.5	Recovery Chamber	. 2-6
		2.5.6	Vent to Atmosphere	.2-6
		2.5.7	Draining of the PAS	. 2-6
		2.5.8	V-belt Transmission	. 2-7
		2.5.9	Motors	. 2-7

#### 2 OPERATING DESCRIPTION

#### 2.1 Technical Characteristics

#### DIMENSIONS

Width x height x length	225 x 450 x 490 mm including motor, filter and mounting bracket
Weight	37 kg
Suction pipe	Ø 1.5 or 2 inches (40 l/min) Ø 2 inch (80 and 130 l/min)
Inlet of the filter housing	DN Ø 40/49 mm (1.5")

PAS type	Motor power	Ø of motor pulley	Ø of pump pulley
PAS 80	1 kW / 1400rpm	95 mm	150 mm
PAS 130	1.5 kW / 2800rpm	71 mm	150 mm

#### HYDRAULIC PERFORMANCES

The hydraulic performances mentioned below are for a standard installation (one pump on piping to the tank). The pump has a static lift of 4m, a pipe diameter of 2 inches and a length of 40m. The fuel temperature is 20°C.

Flow rate:	40 and 80 l/min (motor of 1 kW) or 130 l/min (motor of 1.5 kW)
Pressure:	$1.7 \le P \le 3.5$ bar for PAS V3 80 l/min $2.3 \le P \le 3.5$ bar for PAS V3 130 l/min
Suction capacity:	vacuum pressure dry pump is 400 mbar, vacuum pressure wet pump (with oil) is 900 mbar
Pump intake depth	0.5 to 4.5 meters
Air separator	fulfils the EEC regularisation for systems without sight glass
Filters	12 or 25 $\mu$ m paper mesh and 90 $\mu$ m plastic mesh (can be cleaned and re-used). The filter can easily be replaced without spillage, and without losing the priming on the suction line due to the foot valve in the bottom of the filter box.
Liquids	fuels with a viscosity lower than $10^{-4} \text{ m}^2/\text{s}$
Minimum inlet vacuum for correct operation	100mB @ 80 l/min 150mB @ 130 l/min

#### **ENVIRONMENTAL CONDITIONS**

Climate	Marine, tropical, industrial and polar
Ambient temperature range	-40 °C to +55 °C
Temperature of liquid	-25°C to +25°C
Relative humidity	5% to 95% non condensing
Altitude	Sea level up to 2000 m

#### 2.2 Alignment of the Pump

When installing the PAS V3 the following measures have to be taken concerning the V-belt.

Adjust the pulleys of the motor and pump in such a way that they are positioned in one plane. A flat plate can be used to position the pulleys correctly. In this case the plate has to touch the pulleys at 4 points (see picture).



If a tensioning roller (optional) is used, the v-belt should run in the middle of this roller. This has to be checked during running of the pump.



#### 2.3 Schematic Diagram of Operating Principles

#### 2.4 Schematic Diagram References

- 1) Inlet pipe
- 2) Foot valve
- 3) Filter
- 4) Gear pump
- 5) Drain
- 6) Float system
- 7) Vent float (non overflow device)
- 8) Vent
- 9) Top vent plug
- 10) Recovery chamber
- 11) Permanent air separation leak
- 12) Vortex regulating valve
- 13) Low pressure air separation leak
- 14) Low pressure vortex valve
- 15) Outlet valve reference to atmosphere
- 16) By-pass
- 17) Vortex centrifugal inlet

Issue B

- 18) Air separation channel
- 19) High-pressure chamber
- 20) Drain and pressure plug
- 21) Outlet valve seat
- 22) Outlet valve
- 23) Outlet valve spring
- 24) Aeration valve

#### 2.5 Operating Description

#### 2.5.1 PUMPING, FILTRATION & BY-PASS

The fuel held in the tank underground is raised by the gear pump [4] and passes through the filter [3] and the foot valve [2].

The gear pump forces the product through the vortex system [17] into the high-pressure chamber [19].

When the flow pressure exceeds the reference pressure, adjusted by the bypass screw, the by-pass valve [16] opens and the excess fuel in the high-pressure chamber [19] is channelled back to the intake. Thus, the outlet pressure is kept constant regardless of the flow drawn off by the fuel distribution hose(s).

#### 2.5.2 ABOVE GROUND TANK APPLICATIONS

The PAS V3 pump has been specifically designed to work in conjuction with underground tanks where the fuel level inside varies between 0.5 and 4 meters below the pump shaft.

If the fuel in the tank can rise above this level, then we do not recommend you use the PAS V3 pump.

Should there be no other option available, then the following precautions must be taken:

1) Install a special "Tokheim 52 Valve" between the tank and the inlet of the pump.

For VHS applications, you are required to use 2 of these valves in parallel.

2) Install a 1 in. solenoid valve between the tank and the inlet of the Tokheim 52 Valve.

For VHS applications, you are required to use 2 of these valves in parallel

The valve(s) should only be opened when the pump is running.

Note: This installation must be done in accordance with all local safety legislation.

#### 2.5.3 AIR SEPARATION

The flow is channelled tangentially into the vortex where the shape of the inlet [17] imparts a helical movement to the flow producing a centrifugal effect.

the heavier liquid product molecules in the flow forced by the centrifugal pressure towards the outside walls of the vortex channel and then directed away to the high-pressure chamber. The lighter air/vapour molecules remain trapped in the centre of the vortex channel and are then directed away through the vortex tube, the vortex valves into the recovery chamber.

The purpose of the vortex valves is regulating the flow at different pressures. The pressure depends on the amount of air in the flow. From the vortex valves the particles move into the recovery chamber [10].

The vortex body exists of two valves in parallel:

#### • The vortex regulating valve [12]

A piston spring loaded valve, which gives a constant headloss between the air separation channel and the recovery chamber. This valve stays open to keep the air separation system working at any pressure or flow.

#### •Low-pressure vortex valve [14]

A piston spring loaded valve, which opens when the pressure is less than 1 bar.

#### 2.5.4 OUTLET VALVE

Once the liquid has had the air/vapour extracted, it enters the high-pressure chamber located on the down-stream circuit after the vortex. Here a spring loaded non-return outlet valve [22] performs the dual function of:

- An authorisation valve (opening when the pressure is sufficient),
- A non-return valve which will keep pressure on the measuring system. This is necessary to avoid start up errors at the next pumping cycle. In the valve a pressure overload vent limits this pressure.

An aeration valve is placed on the other side of the outlet-channel. This valve is open on low pressure (up to 0.7 bar) and closes on higher pressure. This means it is open on high air intakes, which will keep the pressure low and the outlet valve closed. On lower air intakes it closes which will close the internal leakage and increases the maximum flow. The PAS is then ready to distribute fuel when the nozzle is opened.

#### 2.5.5 RECOVERY CHAMBER

In the recovery chamber [10] the following flows are collected back:

- the vapour/ liquid flow from the central canal of the vortex [18]
- the flow through the aeration value in the outlet channel [24] (only when the pressure is < 0.7 bar)

Together these flows, necessary for the functioning of the system, are about 8 l/ min. These flows are brought back to the pump inlet by the recovery float valve [6].The specially designed recovery float valve maintains the liquid at a constant level.

#### 2.5.6 VENT TO ATMOSPHERE

A vent [8], located at the highest point on the cover, maintains the recovery chamber at atmospheric pressure.

The gas that is extracted from the central channel of the vortex is released into the atmosphere by this vent. According to some local regulations, a pipe or hose must be connected to this vent.

A non-overflow device [7], made by a floating valve is put in the vent channel.

# <u>NOTE:</u>- If this vent (internal thread R 3/8") is connected to an atmospheric pressure equalising pipe, the pipe has to have a minimum internal diameter of 12mm.

#### 2.5.7 DRAINING OF THE PAS

The PAS V3 is provided with a double drain [5] located at the lowest point of the housing. The pump can easily be drained without spillage. Therefore the following actions must be carried out:

• open the filter box

• remove the foot valve (to let the fuel go back to the tank underground)

• unscrew the drain [5] and pull it one level down to empty the recovery chamber [10] in the filter box

If the fuel can not go back to the tank underground (e.g. non-return valve in the pipeline, ground tank higher than pump), the draining is still possible by unscrewing the drain screw [5] completely and catch the fuel in a tank.

#### 2.5.8 V-BELT TRANSMISSION

In the new range of dispensers, Quantium T range, the motor is fixed on the PAS support which can be adjusted in order to get the right tension. A spring roller (optional) is also available to get the correct tension.

For the Quantium T-range the following V-belts are used:

- For 80 l/min pumps (is with a SPA 95 pulley) the V-belt has Tokheim code number 900028-004.
- For 130 l/min pumps (is with a SPA 71 pulley) the V-belt has Tokheim code number 900028-005.
- For all other dispenser models check the code on the old V-belt before ordering, different V-belts may be used.

#### 2.5.9 MOTORS

The power that is required is proportional to the flow rate and pressure:

- For the 80 l/min version: 1 kW at 1400 rpm
- For the 130 l/min version: 1.5 kW at 2800 rpm

The motors correspond to European safety regulations: EExd

The body of the motor must always be earthed. The motors supplied are D 230 V/50 Hz and Y 400 V/50 Hz; other specifications can be delivered on demand.

## CONTENTS

3	FAII	LURE DI	AGNOSIS	
	3.1	Failure	Diagnosis	
	3.2	Flow C	harts	
		3.2.1	No Fuel Flow	
		3.2.2	Reduced Fuel Flow	
		3.2.3	Uneven Fuel Flow	
		3.2.4	Closing of the Overflow Valve	
		3.2.5	Excessive Noise	

#### 3 FAILURE DIAGNOSIS

#### SAFETY

- 1) Take the standard safety measures into account: place safety equipment and signs and switch off the electric power supply.
- 2) When the PAS V3 is stopped make sure that the pump is not pressurised due to closing of the vent float valve. When unscrewing the top vent plug (reference [9] in the schematic diagrams of operating principles), the pressure can be released by pushing the float down carefully with a pin.



Open the vent plug

If there is no air coming from the air-vent when the filterbox cover is removed, the vent float is closed and the PAS pressurised. By pushing a small screwdriver or pin through the hole, the pressure can be released.

#### 3.1 Failure Diagnosis

- 1) No fuel flow
- 2) Reduced fuel flow
- 3) Uneven (pulsing) fuel flow
- 4) Closing of the overflow valve
- 5) Excessive noise
  - Prior fault diagnosis/search:
  - Check the condition of the belt drives.
  - Following any repair action :

Make sure that all the necessary procedures required by Weights & Measures and Safety are fully applied.

#### **REMARK**

Once an O-ring has been removed, it must not be re-used.

#### 3.2 Flow Charts

3.2.1 NO FUEL FLOW



3.2.2 REDUCED FUEL FLOW



#### 3.2.3 UNEVEN FUEL FLOW



#### 3.2.4 CLOSING OF THE OVERFLOW VALVE



#### 3.2.5 EXCESSIVE NOISE



This page is intentionally blank

## CONTENTS

4	TROU	JBLESHOOTING 4-2	2
	4.1	Outlet Pressure	)
	4.2	Inlet Pressure	2
	4.3	Air Vent	3
	4.4	Internal Air Entry in the Pump	3
	4.5	External Problems up-stream the PAS 4-4	1
	4.6	Excessive Head Loss	1
	4.7	Air Entry on the Pipework to the Storage Tank 4-5	5

#### 4 TROUBLESHOOTING

#### 4.1 Outlet Pressure

The flow of the PAS V3 is regulated with the outlet pressure. To adjust the outlet pressure:

- Unscrew the pressure plug (see reference [20] in the schematic diagram) with dimensions M10 x 1.0 spanner size 17.
- Connect the pressure gauge via the flexible pipe into the hole of the outlet-cover (See section 5.3 for specific tools).
- Take the nozzle out of the dispenser and when the pump starts to run (nozzle is still closed), check the pressure at the pressure gauge. On top of the by-pass cover a + and show in which way the by-pass screw must be turned to increase (+) or decrease (-) the pressure. When the desired pressure is adjusted, check whether a correct flow is reached.

The pressure value depends on installation characteristics. However when adjusting the outlet pressure, the following values for the pressure are to be respected:

- For the PAS V3 80 l/min models the normal working pressure in by-pass mode should be between 2 and 2.5 bar, and should always be > 1,7 bar.
- For the PAS V3 130 l/min models, the pressure should be between 2.5 and 3.5 bar.

For dispensers delivering 9.6 m<sup>3</sup>/h (two PAS 80 pumps in parallel), the pressure of one pump has to be 0.2 bar higher than the other one  $\infty$ 



#### 4.2 Inlet Pressure

The inlet pressure can be measured by using a special filter box cover (see section 5.4) and a pressure gauge (range -1 bar up to 3 bar).

At full flow (2 nozzles of 40 l/min) the inlet pressure measured is the pressure loss caused by the resistance of the site configuration (height of pump in comparison to the reservoir and length of pipe work).

If the inlet pressure is too high, check:

- if the filter is clean
- correct working of the foot valve
- installation up to the reservoir (non-return valve, dirt blocking the flow, tank filter clogged, and so on).

#### 4.3 Air Vent

Place one end of a tube (inner diameter 12 mm) with a 3/8" BSP thread coupling on the vent and drop the other end of the tube in a small tank with fuel (same fuel as tank).

Start the pump in by-pass mode by removing the nozzle from its holder and let it run for a while before opening the nozzle.

- When bubbles appear constantly, it means that there is an air entry in the pump or the installation before the pump
- If the fuel is sucked into the pump, the recovery float valve is not closing properly



Put the tube in the tank (not too deep), and check if there are bubbles

#### **NOTE**

If the vent is difficult to reach:

Try to feel with your hand if a stream of air or vapour is expelled from the vent.

#### 4.4 Internal Air Entry in the Pump

Below a list of possible causes for air to enter the pump:

- 1) Filter cover O-ring incorrectly positioned or dilated.
- 2) O-ring between filter box and PAS body incorrectly positioned or dilated.
- 3) One of the sealing rings between the connection to ground piping and filter box is defective or insufficiently tightened.
- 4) Float assembly blocked in an open position, installed incorrectly or a loose particle is in between.

#### 4.5 External Problems up-stream the PAS

1) If there is a non-return valve, check its proper operation.

\*Defective non-return valve (if mounted according to dispenser model):

Replace the valve.

2) Check the volume meter is not blocked

\*If blocked, replace the volume meter.

3) Check condition of the nozzle filter and of the nozzle

\*Filter of the nozzle clogged. Clean filter when necessary.

4) Check whether the electronic valve is working

\*Electronic valve is blocked. Replace the electronic valve.

#### 4.6 Excessive Head Loss

When the ambient temperature increases, the ability to pump fuel is reduced (formation of vapour locks): check if the pipe work and manifold are sufficiently insulated (as installed) from ambient heat sources.

To reduce the temperature build-up the manhole chimneys can be filled with sand and the manhole covers can be painted white.

If a satisfactory technical solution cannot be found, try to maintain normal operation by keeping the storage tank filled as much as possible, this will reduce problems coming from high ambient temperatures.

- 1) Check the head loss resulting from the specific configuration of each fuel line by comparing the measured head loss under each dispenser at the point where the same fuel from the same underground storage tank arrives.
  - If these various measured head loss values are comparable:
    - ⇒ Check the expected (theoretical) head loss values are indeed comparable to those measured. If not the line may be obstructed by an unknown object.
  - If these various measured head loss values are not comparable:
    - ⇒ Check the connection between each PAS and the relevant underground pipe work (manifold, non-return valve blocked).
- 2) Check the PAS filter.
- 3) If the dispenser is the only one delivering this product, check the complete line, noting the distance between the pump and the storage tank (take care of the way of piping), the height of the product in the tank, the various accessories (plugs, valves, and so on). Usually an easy way to solve the problem is to fill the tank before trying to cool down the fuel.

#### 4.7 Air Entry on the Pipework to the Storage Tank

Check if there is a leak in the fuel piping from the storage tank to the dispenser.

In the piping systems with more than one pump per suction line, check the non-return valves on each derivation when present.

If there are no special valves for this purpose, the valves of the filter box take over this function (they must exist on all dispensers). It is possible that one of these valves is not closing properly and is allowing air into the pipeline. When the problem can not be found, it is possible to mount a sight glass underneath the pump filter box to check for leakages and to define the leakage (contact Tokheim Hydraulic Department).

The wrong foot valve can be detected by delivering about 20 litres with each pump and check if the delivery is immediately starting when the motor starts and stays constant.

After visual checking the parts of the pipeline (valves, hinges, bent pipes, and so on) get in touch with specialised departments to make a hydraulic improvement on the fuel piping. This page is intentionally blank

## CONTENTS

5	SPAI	<b>RE PARTS AND MAIN</b>	TENANCE TOOLS	5-3
	5.1	Frequently Used Spare	e Parts	5-3
	5.2	Exploded Views and Pa	Parts Lists	5-4
		5.2.1 Front View		5-4
		5.2.2 Back View		5-6
		5.2.3 Top View		5-10
	5.3	Maintenance Kits		5-12
	5.4	References of Specific	Tools	5-15

This page is intentionally blank

## 5 SPARE PARTS AND MAINTENANCE TOOLS

### 5.1 Frequently Used Spare Parts

Reference	Description
902373	Pump pulley SPA 150
901321-002	Key A6 x 6 x 30 for motor and pump pulleys
900050-027	O-ring Viton Ø 4 x 120 for filter box cover
900050-002	O-ring Viton Ø 4 x 34 for outlet flange of PAS
901614	Paper filter 12 µm Gasoline (according to country specification)
901613	Paper filter 25 µm Diesel (according to country specification)
901612	Cleanable plastic filter 90 µm mesh, all fuels.
900028-004	V-belt A29/13 13A760MC used in Quantium T with 95 mm pulley
900028-005	V-belt A27/13 13A720MC used in Quantium T with 71 mm pulley
* * * * * * * * *	With V-belts always: check code on V-belt before ordering



9

2

16

14

15

18

4

17

19

**Exploded Views and Parts Lists** 

8

5.2

TF

12



### FRONT VIEW PARTS LIST

Item No	Description	Désignation Français	Part No	Comments
1	Ring Retain Bore D50	Anneau Elast Int D50	900049-002	
2	O-ring 105.00x3.50	Joint Torique 105.00x3.50	900050-023	
3	Ball Bearing D20xD47x14	Roulement a Billes D20xD47x14	900070-001	
4	Screw Torx SHC M6x20	Vis Torx CZX M6x20	900356-001	
5	Screw Torx SHC M6x25	Vis Torx CZX M6x25	900356-002	
6	Cotter Pin 6x6x40	Clavettes Paralleles 6x6x40	901321-001	
7	Cotter Pin 6x6x30	Clavettes Paralleles 6x6x30	901321-002	
8	Parallel Pin 6x20mm	Goup cyclind C 6x20mm	901348-001	
9	Lip Seal 25x35x6	Joint de Levre 25x35x6	901350-001	
10	Label PAS V3	Etiquette PAS V3	901662	
11	Pulley SPA150	Poulie SPA150	902373	
12	Assy main housing	Asm cuve	902377	
13	Pump flange	Flasque de pompe	902378	
14	Pinion	Pignon	902381	
15	Crown	Couronne	902382	
16	Pump shaft	Axe de pompe	902387	
17	Vortex/housing seal	Joint vortex/cuve	902389	
18	Vortex cover	Plaque de vortex	902392	
19	Pump shaft bearing brush	Palier axe de pompe	902397	



PAS

V3 Pump for Fuel Dispensers

**Component Technical Manual** 

BACK	VIEW	PART	IS LIST
------	------	------	---------

Item No	Description	Désignation Français	Part No	Comments
1	Washer PI M10	Rondelle PI M10	900008-014	
2	Washer Serr Lock Ext M6	Rondelle a Dents DEC M6	900009-004	
3	Nut Hex M6	Ecrou Hex M6	900011-001	
4	O-ring 31.00x3.00	Joint Torique 31.00x3.00	900050-017	
5	O-ring 6.00x2.30	Joint Torique 6.00x2.30	900050-020	
6	O-ring 35.00x3.00	Joint Torique 35.00x3.00	900050-024	
7	O-ring 46.00x3.00	Joint Torique 46.00x3.00	900050-026	
8	Screw Torx SHC M6x25	Vis Torx CZX M6x25	900356-002	
9	Outlet valve seal	Siege valve de sortie	900638	
10	Outlet insert	Boite de sortie	900639	
11	Outlet cover	Couvercle de sortie	900640	
12	Vortex piston	Piston de vortex	900642	
13	Outlet valve disc	Disque valve de sortie	900645	
14	Outlet valve washer	Rondelle valve de sortie	900646	
15	Vortex piston spring	Ressort piston de vortex	900649	
16	Outlet valve body	Corps valve de sortie	901192	
17	Aeration valve assy	Clapet d'aeration assemblee	901700	
18	Vortex valve spring	Ressort valve de vortex	901701	
19	Vortex valve piston	Piston valve de vortex	901702	
20	Outlet valve spring	Ressort valve de sortie	901703	
21	Schrader valve	Mecanisme de valve Schrader	901790	
22	Bypass valve	Clapet de bypass	902368	
23	Assy bypass screw	Vis de bypass montee	902369	

(CONT.)

Document Ref 903647-001 Rev 3

5.2.2 BACK VIEW (CONT.)



**Component Technical Manual** 

## BACK VIEW PARTS LIST (CONT.)

Item No	Description	Désignation Français	Part No	Comments
24	Bypass spring	Ressort de bypass	902370	
25	Bypass damper	Assourdisseur de bypass	902371	
26	Bypass cover	Couvercle de bypass	902374	
27	Drain screw M10x1.00	Bouchon M10x1.00	902375	
28	Flat Seal D10x18x1	Joint Plat D10x18x1	902376	
29	Vortex valve body	Corps valve de vortex	902383	
30	Vortex valve tube	Tube valve de vortex	902384	
31	Vortex valve cover	Couvercle valve de vortex	902385	
32	Vortex valve cover seal	Joint couvercle valve de vortex	902395	
33	Drilled screw M6x20	Vis percee M6x20	902399	

Document Ref 903647-001 Rev 3



#### TOP VIEW PARTS LIST

Item No	Description	Désignation Français	Part No	Comments
1	Washer Serr Lock Ext M8	Rondelle a Dents DEC M8	900009-002	
2	Nut Hex M8	Ecrou Hex M8	900011-003	
3	Screw HSHC M6x60	Vis CHC M6x60	900017-001	
4	O-ring 8.00x2.00	Joint Torique 8.00x2.00	900050-021	
5	O-ring 14.00x2.00	Joint Torique 14.00x2.00	900050-022	
6	O-ring 82.14x3.53	Joint Torique 82.14x3.53	900050-025	
7	O-ring 120.00x4.00	Joint Torique 120.00x4.00	900050-027	
8	Screw Torx SHC M6x20	Vis Torx CZX M6x20	900356-001	
9	Screw Torx SHC M6x25	Vis Torx CZX M6x25	900356-002	
10	Sticker filterbox cover	Autocollant couvercle boite de filtre	900636	
11	Nut Hex Serpress M6	Ecrou Serpress M6	901295-001	
12	Washer Spring Retain Shaft D	Anneau D'Arret pour Axe D3	901313-001	
13	Vent Float Nipple	Raccord de flotteur d'event	902372	
14	Filter - 90 micron	Filtre - 90 micron	901612	Standard
	Filter - 25 micron	Filtre - 25 micron	901613	Option
	Filter - 12 micron	Filtre - 12 micron	901614	Option
15	Valve housing	Corps de valve	901663	
16	Needle valve	Valve de aiguille	901664	
17	Gland Nut	Ecrou de joint	901665	
18	Cork float	Flotteur de liege	901666	
19	Foot valve guide	Guide clapet	901690	
20	Foot valve flat seal	Joint de clapet	901691	
21	Foot valve head	Tete clapet	901692	
22	Spring plate	Plaque supp equipee	901693	
23	Filter box cover	Couvercle boite de filtre	901694	
24	Stud M6x40 (18-4-18)	Goujon M6x40 (18-4-18)	901695	
25	Vent Body Plug	Bouchon d'event	902006	
26	Flat Seal D10x18x1	Joint Plat D10x18x1	902376	
27	Housing cover	Couvercle de cuve	902379	
28	Cover meter support	Couvercle liaison mesureurs	902380	
29	Recovery valve assy	Vanne de recup asm	902386	
30	O-ring filterbox support	Joint platine BAF	902388	
31	Cover seal	Jiont couvercle	902390	
32	Drain screw	Vis de purge	902391	
33	Recovery float	Flotteur de recuperation	902393	
34	Drain screw flat seal	Joint plat vis de purge	902394	
35	Meter support cover seal	Joint liaison mesureurs	902396	
36	Filterbox	Boite de filtre	902398	

#### 5.3 Maintenance Kits

















902324	Tool for disassembling outlet insert (refer to Page 39 - part nos 17,10,4,9)
9231221014	Filter box cover for pressure measuring (vacuum)
9231221013	Filter box with pressure point before foot valve
9508012519	Flexible extension (male/female) M10 x 1.00 for pressure measurement
SR	Manometer (-1 to 3 bar) to measure pressure or vacuum
SR	Torx key (shape T30)
902325	Tool for mounting lip-seal (refer to Page 37 - part no 9)
902327	Tool for mounting outlet valve seat (refer to Page 39 - part no 9)
902328	Vortex remover (refer to Page 39 - part nos 30,19,12,18,15,29)
	Note : remove from the front of the pump to the back

### 5.4 References of Specific Tools

SR: Tools from local stores.

This page is intentionally blank

## CONTENTS

#### 6 PROBLEM REPORT FORM FOR THE PAS V3 PUMP

Issued by:	Report date:	
Station name:	Meter reading 1:	I
city:	Meter reading 2:	I
country:	Ground piping:	
PAS V3 no.:	-Length	m
Installation date:	-Height	m
Kind of fuel:	-Diameter	m
Dispenser type:	More pumps on one pipeline	≽yes ≽no
Problem description		
> 1. No fuel flow		
a) Is the pump running?		≽yes ≽no

lf a	<ul> <li>a) Is the pump running?</li> <li>b) Is the pump unusually noisy?</li> <li>the answer is yes, go to point 4. If the answer is no:</li> <li>c) Is there enough fuel in the underground tank?</li> </ul>		yes yes yes		no no no
	<ul> <li>d) Is air coming out of the air vent?</li> <li>e) What is the outlet pressure (measured at the outlet plug)?</li> </ul>	~	yes	4	no mbar
A	<ul><li>2. Reduced fuel flow</li><li>a) What is the outlet pressure when running in bypass mode?</li><li>b) What is the inlet pressure at the filter box?</li><li>c) Are the following parts in good order: is the filter box clean, v-belt?</li></ul>	~	yes	~	_bar _mbar _no
4	<ul><li>3. Pulsating flow</li><li>a) Is the outlet pressure constant?</li><li>b) Is air coming out of the air vent?</li></ul>	AA	yes yes	AA	no no
A	<ul> <li>4. Excessive noise</li> <li>a) Is the noise coming from inside the pump?</li> <li>b) What is the outlet pressure in bypass mode?</li> <li>c) What is the inlet pressure at the filter box?</li> </ul>	>	yes	>	no _bar mbar
	d) Is it cavitation noise?	$\succ$	yes	≻	no

#### Cause of the Problem

#### Actions done to solve the problem (list part numbers of new parts used)

#### Further actions required

#### Remarks about special environmental or other circumstances

This page is intentionally blank

#### 🕦 Spare Parts GB Manufacturing Manufacturing Koppens Automatic (Bladel) Unit 3, Baker Road Route de Soliers Industrieweg 5 West Pitkerro Industrial Estate 14540 Grentheville 5531 AD Bladel Dundee DD5 3RT BP268, Caen Cedex 14013 The Netherlands Scotland France +31 497 389 555 +44 (0)1382 598000 2 +33 231 15 15 15 +31 497 381 950 +44 (0)1382 598001 +33 231 23 15 06 í í SALES & SERVICE DIVISIONS MIDDLE EAST, SOUTH & CENTRAL EUROPE AMERICA Austria Netherlands Export Division Tokheim Austria GMBH ZAC Paris Nord 2 Tokheim Netherlands B.V. B.P. 40027 Tremblay-en-France Eitzenberger Strasse 4-6 Touwslagerstraat 17 A-2544 Leobersdorf Postbus 4186 95912 Roissy C.D.G. Cedex **2 +43 (0) 2256 606 0** 2980 GD Ridderkerk France +43 (0) 2256 606 170 +31(0) 180 48 15 00 +33 (0)1 49 90 77 56 +33 (0)1 49 90 77 93 Solution office@leobersdorf.tokheim.com +31(0) 180 48 15 55 marcom@tremblay.tokheim.com Sales@ridderkerk.tokheim.com Belgium PD Poland AFRICA **RFC** Cameroon Tokheim Pol-Germann Tokheim Sp. z.o.o. Everdongenlaan 31 ul. Narwicka 1 Socatam S.A. 2300 Turnhout BP 3941 PL-80-557 Gdansk +32 (0) 14 44 85 00 +48 58 343 21 71 Douala **\*** +237 40 57 86 +32 (0) 14 44 85 55 1 +48 58 343 22 15 +237 40 57 88 Sales@turnhout.tokheim.com Digermann@tokheim.pl socatam.douala@camnet.cm CZ Czech Republic Portugal Morocco Tokheim G.N.C. Matam S.A Pernerova 48 Parque de Ciencia e Tecnologia 209 Bld Moulay Ismail Route de Rabat Edificio Tecnologia 1, Nº 27 CZ-18602 Prague 8 ☎ +420 224 890 312 2780-920 Oeiras Casablanca +420 222 327 267 Lisboa +212 22 40 40 24 pribrsky@prague.tokheim.com +351 214 220 420 +212 22 40 40 21 +351 214 214 226 創 🖾 matam@wanadoo.net.ma DK Denmark & Scandinavia **RUS** Russia & CIS Countries SN Senegal Tokheim Scandinavia A/S Tokheim Representative Office Cosetam S.A. Hejrevang 10 Room 313, Hotel "Ukraina" Quartier de Bel Air 3450 Allerød Kutuzovski Prospekt, 2/1 Route des Hydrocarbures +45 48 13 45 45 Stroyenie 1 BP 1237 +45 48 17 45 96 Moscow 121249 Dakar +7 095 933 69 35 service@alleroed.tokheim.com +221 832 23 71 +7 095 933 69 34 Í +221 832 68 34 kolobov@dol.ru cosetam@ns.arc.sn France - Le Plessis SK Slovak Republic ZA South Africa Tokheim Services France Tokheim Tokheim South Africa Ltd 9 Avenue Galilée Mlynske Nivy 70 Stand 110, Precision Road 92350 Le Plessis-Robinson SK-82015 Bratislava Kya Sand +33 (0)1 41 36 13 00 +421 2 58 27 02 15 Randburg +33 (0)1 41 36 13 70 +421 2 52 41 41 23 俞 **\*** +27 11 462 2105 info@tokheim-services.com schroeder@berlin.tokheim.com +27 11 462 1942 ☑ tokheimsales@tokheim.co.za **F** Tokheim Europe & Africa Headquarters E Spain TIN Tunisia ZAC Paris Nord 2 Tokheim Koppens Iberica S.A. Cottam SARL B.P. 40027 Tremblay-en-France Calle La Granja, 41 95912 Roissy C.D.G. Cedex Poligono Industrial de Alcobendas

#### D Germany

Tokheim GmbH Lothstrasse 1a D-80335 München ☎ +49 (0)89 189 53 0 意 +49 (0)89 189 53 148 ⊠ service@muenchen.tokheim.com

#### 🕕 Italy

 Tokheim Sofitam Italia S.r.l.

 Quattordio Km 10800

 S.P. 26

 14030 Scurzolengo (AT)

 ☎ +39 0141 2038200

 ᡎ +39 0141 2038222

 ☑ info@asti.tokheim.com

Tokheim Koppens Iberica S.A. Calle La Granja, 41 Poligono Industrial de Alcobendas 28108 Alcobendas (Madrid) **2** +34 91 2030465 **1** +34 91 6614130 Surra@madrid.tokheim.com

#### CII Switzerland

 Tokheim Switzerland AG/SA/LTD

 Route du Crochet 7

 Case Postale 50

 1762 Givisiez

 2 +41 (0)26 460 51 11

 +41 (0)26 460 51 12

 Image: Section of the section of the

#### GB United Kingdom

Unit 1, Baker Road West Pitkerro Industrial Estate Dundee DD5 3RT Scotland ■ +44 (0)1382 483500 ■ +44 (0)1382 731835 ⊠ service@tokheimuk.com Cottam SARL 116 Ave de l'Union du Maghreb Arabe BP 117 La Soukra 2036 Tunis ☎ +216 175 95 50 ↓ +216 175 95 30 ⊠ cottam@cottam.com.tn

#### ASIA

➡ Tokheim
 PO Box 16869
 JAFZ
 Dubai, UAE
 ☎ +971 4 881 3305
 ᡎ +971 4 881 4463
 ☑ tokheim@emirates.net.ae

As Tokheim regularly improves its products to ever better respond to evolving market and regulatory requirements, it reserves the right to change any of the specifications of these products, and this without prior notice.

For technical manual enquiries, contact: author@dundee.tokheim.com